

PLEASE NOTE

IMPORTANT

MAKE THE FOLLOWING CHANGES IN THE CAI/O INTERFACE MODULE OPERATION MANUAL

PAGE 7 BOTTOM OF PAGE

CHANGE: IF YOUR COMPUTER IS THE MAIN DEVICE IT IS CALLED A DCE (DATA COMMUNICATION EQUIPMENT) AND YOU WILL USE A MALE DB-25. IF YOUR COMPUTER IS TO BE A TERMINAL TO A MAIN COMPUTER THEN IT IS A DTE (DATA TERMINAL EQUIPMENT) AND USES A FEMALE DB-25.

TO READ: IF YOUR COMPUTER IS THE MAIN DEVICE IT IS CALLED DCE (DATA COMMUNICATION EQUIPMENT) AND YOU WILL USE A FEMALE DB-25. IF YOUR COMPUTER IS TO BE A TERMINAL TO A MAIN COMPUTER THEN IT IS A DTE (DATA TERMINAL EQUIPMENT) AND USES A MALE DB-25.

PAGE 8 TOP OF PAGE

CHANGE: DCE (MALE BD-25) TO DCE (FEMALE BD-25)

CHANGE: DTE (FEMALE DB-25) TO DTE (MALE DB-25)

PAGE 12 PARALLEL TEST

CHANGE: 40 POKE K,I TO READ 40 POKE K,I

CAI Instruments Inc.
P.O. Box 2032
Midland, MI. 48640
(517) 835-6145